



Catalog Number: E-335

**Detection Range:**1 pmol/L -50 pmol/L

### Principle:

The kit assay Rat T3 level in the sample, use Purified Rat T3 antibody to coat microtiter plate wells, make solid-phase antibody, then add T3 to wells, Combined T3 antibody which With HRP labeled, become antibody - antigen - enzyme-antibody complex, after washing Completely, Add TMB substrate solution, TMB substrate becomes blue color At HRP enzyme-catalyzed, reaction is terminated by the addition of a sulphuric acid solution and the color change is measured spectrophotometrically at a wavelength of 450 nm. The concentration of Rat T3 in the samples is then determined by comparing the O.D. of the samples to the standard curve.

1	wash solution	20ml×1bottle	7	Stop Solution	6ml×1 bottle
2	HRP-Conjugate reagent	6ml×1 bottle	8	Standard (80pmol/L)	0.5ml×1 bottle
3	Microelisa stripplate	12well×8strips	9	Standard diluent	1.5ml×1bottle
4	Sample diluent	6ml×1 bottle	10	Instruction	1
5	Chromogen Solution A	6ml×1 bottle	11	Closure plate membrane	2
6	Chromogen Solution B	6ml×1 bottle	12	Sealed bags	1

# Materials and components

# Storage/Stability:

Store at 4°C/6Months

# Note for Sample:

1. Samples to be used within 5 days may be stored at  $2-8^{\circ}$ C, otherwise samples must stored at  $-20^{\circ}$ C (1 month) or  $-80^{\circ}$ C (2 months) to avoid loss of bioactivity and contamination.

2. Tissue or cell extraction samples prepared by chemical lysis buffer may cause unexpected ELISA results due to the impacts of certain chemicals.

3.Can't detect the sample which contain NaN3, because NaN3 inhibits HRP active.

#### Assay procedure

1. Dilute and add sample:Dilute Original density Standard as follow table:

40pmol/L	5 Standard	150µl Original density Standard+150µl Standard diluent
20pmol/L	4 Standard	150µl 5 Standard+150µl Standard diluent
10pmol/L	3 Standard	150µl 4 Standard+150µl Standard diluent
5pmol/L	2 Standard	150µl 3 Standard +150µl Standard diluent
2.5pmol/L	1 Standard	150µl 2 Standard +150µl Standard diluent

2. Add sample: Set blank wells separately (blank comparison wells don't add sample and HRP-Conjugate reagent, other each step operation is same). testing sample well. add standard 50µl in the Microelisa stripplate accurately,add Sample dilution 40µl to testing sample well, then add testing sample 10µl (sample final dilution is 5-fold), add sample to wells , don't touch the well wall as far as possible, and Gently mix.

- 3. Incubate: After closing plate with Closure plate membrane ,incubate for 30 min at 37 °C.
- Configurate liquid: 30-fold(or 20-fold) wash solution diluted 30-fold (or 20-fold) with distilled water and reserve.
- 5. Washing: Uncover Closure plate membrane, discard Liquid, dry by swing, add washing buffer to every well, still for 30s then drain, repeat 5 times, dry by pat.
- 6. Add enzyme: Add HRP-Conjugate reagent 50µl to each well, except blank well.
- 7. Incubate: Operation with 3.
- 8. Washing: Operation with 5.
- 9. Color:Add Chromogen Solution A 50ul and Chromogen Solution B 50ul to each well, evade the light preservation for 10 min at 37 ℃
- 10.Stop the reaction:Add Stop Solution50µl to each well, Stop the reaction(the blue color change to yellow color).
- 11. Assay:take blank well as zero , Read absorbance at 450nm after Adding Stop Solution and within 15min.



### Calculate

Take the standard density as the horizontal, the OD value for the vertical ,draw the standard curve on graph paper, Find out the corresponding density according to the sample OD value by the Sample curve, multiplied by the dilution multiple, or calculate the straight line regression equation of the standard curve with the standard density and the OD value ,with the sample OD value in the equation, calculate the sample density, multiplied by the dilution factor, the result is the sample actual density.

#### NOTES

- 1. The kit takes out from the refrigeration environment should be balanced 15-30 minutes in the room temperature, ELISA plates coated if has not use up after opened, the plate should be stored in Sealed bag.
- 2. washing buffer will Crystallization separation, it can be heated the water helps dissolve when dilute . Washing does not affect the result.
- 3. add Sample with sampler Each step, And proofread its accuracy frequently, avoids the experimental error. add sample within 5 min, if the number of sample is much, recommend to use Volley .
- 4. if the testing material content is excessively higher (The sample OD is bigger than the first standard well ), please dilute Sample (n-fold), Please diluente and multiplied by the dilution factor. ( xnx5 ) .
- 5. Closure plate membrane only limits the disposable use, to avoid cross-contamination.
- 6. The substrate evade the light preservation.
- 7. Please according to use instruction strictly, The test result determination must take the microtiter plate reader as a standard.
- 8. All samples, washing buffer and each kind of reject should according to infective material process.
- 9. Do not mix reagents with those from other lots.